



How to Rotate Your Tires

This guide will show you how to perform a tire rotation on both sides of the vehicle.

Written By: Shaun MacDonald



INTRODUCTION

Tire rotation ensures even wear on the tires. Front and rear axles support different weights, and will wear differently. Rotating tires allows for even wear on a set of four tires, maximizing the lifespan of the set.

You should rotate your tires every five thousand to ten thousand miles to reduce uneven tire wear.



TOOLS:

- [3/4" socket](#) (1)
 - [Hydraulic Floor Jack](#) (1)
 - [Jack Stands](#) (1)
 - [Socket Wrench](#) (1)
 - [Torque Wrench](#) (1)
-

Step 1 — Using a Floor Jack



- Place the hydraulic floor jack under the vehicle until the **saddle** is directly under the **crossmember**.
- ⓘ The **crossmember** is the long metal support beam that runs underneath from the front fender to the rear fender on both sides of the car.
- ⓘ The **saddle** is the round metal part of the jack that moves upward as you pump the jack up.

Step 2 — Using floor jack to lift car.



- Push downward on the jack's lever to lift the saddle upward so that it contacts the crossmember. Continue pushing downward on the lever to lift the car upward.

Step 3



- Place the jack stand under the jack mounting point.
- ⓘ The jack mounting point is a metallic protrusion beneath each of the car doors.

Step 4



- Raise the jack stand until it contacts the jack mounting point.

⚠ In the event the floor jack fails, the jack stand is designed to prevent the car from falling.

Step 5 — How to Rotate Your Tires



- Once the car is raised, remove the lug nuts with the ratchet attached to a 3/4" socket.

Step 6



- Remove the tire off the **wheel studs** and place it aside.
- The **wheel studs** are the metal bolts sticking out of the wheel hub in the center.

Step 7



- On the same side of the vehicle, go to the rear tire.
- Using a ratchet attached to a 3/4" socket, loosen wheel lug nuts. Do not remove them.
- ⓘ Loosening the lug nuts while the tire is on the ground prevents the tire from spinning.

Step 8



- Place the floor jack under the frame in front of the rear tire.
 - ⚠ Make sure that you are not pressed against the plastic and you are directly on the metal frame of the vehicle.
- Raise the jack until the tire is off the ground.

Step 9



- Remove the lug nuts by loosening them with your hands.

Step 10



- Remove the rear tire. Roll and place the tire onto the wheel studs on the front wheel.
- Tighten the lug nuts using your hand until they are tight.
- Roll the previous front tire to the rear and repeat the tightening process

Step 11



- Using a torque wrench, tighten the lug nuts on each wheel to 80 ft-lbs.
 - ⓘ If a torque wrench is not available, use the ratchet attached to the 3/4" socket to hand-tighten the lug nuts until very tight.

Step 12



- Using an air compressor and the air pressure gauge, fill the front and rear tires to appropriate amount.

Follow these steps in the same order to rotate the tires on the other side of the vehicle.

This document was last generated on 2017-06-18 06:52:37 AM.